



Your WorldTV receiver should automatically download new channels as they become available on the satellite platform. In the event auto-download does not transpire, please utilize the following instructions to bring your set-top box up to date.

Channel Download Instructions:

1. Select channel "1" on your set-top box and then power your box off. At this time, a row of vertical lines will appear on the display.
2. Allow the process to continue until a clock format (00:00) appears on display. This may take a couple of minutes.
3. Once the clock format appears, power-on your set-top box and select your desired channel.
4. If the channel download was unsuccessful, please execute a channel search as explained below.

Channel Search Instructions:

1. Press "Menu" on the your remote control.
2. The menu will appear and "Set Up" will be highlighted in blue.
3. Scroll down to "Search for Channels" until highlighted in blue, then press "OK" on the your remote control.
4. A Satellite Installation Menu will appear. In the middle of the screen there are 2 bars in blue and yellow. When the yellow bar (labeled "Total") shows 100, the Channel Search is complete. The full process takes approximately 2 minutes.
5. Press "Exit" on your remote control, select channel "1" and power-off your receiver. Once the clock format appears, power-on your receiver and select your desired channel.